


**The interface circuit between SH7058F and  
F-ZTAT programming adapter board**



Setting the switches on the HS0008EAUF1H on using SH7058F