ECU : Subaru Impreza STi 2.5 ‘07



Connect as below:

Serial Suite:		ECU Plug:	
Red	to	3 Pins Red	(Power Supply +12 Volt)
Black	to	1 Pins Black	(Ground)



Piasiniengineering info@piasienginnering.it – http://www.piasiniengineering.it
Tel: +39 0342 489060 - Fax: +39 0342 488298

Where to connect the flat cable:



Piasiniengineering info@piasinienginnering.it – http://www.piasiniengineering.it
Tel: +39 0342 489060 - Fax: +39 0342 488298

READ the ECU:





Put a wire (bridge) like in the picture, then connect the flat cable pin following the number like in picture.

Piasiniengineering info@piasinienginnering.it – http://www.piasiniengineering.it
Tel: +39 0342 489060 - Fax: +39 0342 488298

WRITE the ECU:



You have to **remove the bridge used before**, and put another 2 wire(Bridge) like in the picture.



Piasiniengineering info@piasinienginnering.it – http://www.piasiniengineering.it
Tel: +39 0342 489060 - Fax: +39 0342 488298